

Battery Charger

Troubleshooting:

1. When the power switch sites "on" but no LED light up:
 - To check the connection of power cord.
 - To check the connection of socket.
 - To check if the fuse is under normal condition.
2. When the power switch site "on" but red/yellow LED do not light up completely and the fan does not run:
 - To check if the output wire occurs short circuit
3. When the power switch site "on", red LED light up, but green LED flashes and no charger action:
 - To check if the output fuse has severed.
 - To check the connection between output connector and the battery
 - To check if having made a correct connection for the battery polarity
 - To check the battery is connected completely.
4. If the fuse is burned-out as soon as the power switch has been turned on and no effect at all:
 - After having been replaced with another new/same fuse. Please do not dismantle the charger or replace with other larger fuse by yourself.
5. The charger time continues for a long duration (abnormal):
 - To check if the battery has been broken down or aged.
6. The yellow/green LED have flashed over 40 minutes during charging:
 - To check if the battery is broken down.
7. The battery heats (abnormal):
 - To stop charging and check if there are troubles occurred on the charger.